

VIN CHIP MOTORHOME BUNDLE KIT

SUITABLE FOR ALL MOTORHOMES, CAMPERVANS & PANEL VANS

This kit includes all you need to retro fit your motorhome to ensure it is protected by the VIN CHIP Police Forensic Scheme .

Your VIN CHIP Bundle Kit contains:

- 5 x RFID Chips
- 6 x Tamper Evident Labels
- 10 x Tamper Evident Window Lozenges
- 1 x Gas Locker Label
- 1 x Master Window Label
- 1 x Door Warning Label
- 1 x Microdot Applicator
- 1 x UV Pen
- 1 x UV Torch
- 1 x Lint Free Micro fibre cloth



FITTING INSTRUCTIONS

Please read carefully before commencing installation and exercise caution when removing the protective film or backing material of the labels and lozenges as they contain security cuts, and it is possible to damage the item.

Fitting the RFID Chips

When choosing a location for your chips, bear in mind it should be hidden out of sight. One must be located in the cab, with the others in the centre and rear of the habitation area. The underside and back of plastic panels or wooden and laminated surfaces such as cupboards, wardrobes, beds, and the toilet compartment are all potential locations, one should be placed at floor level. Do not apply these RFID chips to a metal surface.

Determine your location for the chip, ensuring that you have a large enough flat area. The surface must be clean and dry, otherwise the adhesive will not bond properly. Remove the backing paper and carefully apply the chip. Please note, the chip has a grab adhesive making it a once only application, so once applied it cannot be removed and relocated. Once adhered expel any air bubbles by firmly rubbing the chip onto the surface with the microfibre cloth. The police scanner can read a chip from outside the motorhome even when it is secured and locked-up.

Using the Ultraviolet Security Pen

A simple and easy way to further enhance the identity of your motorhome is to write your home postcode on any removable items with the UV Pen.

Using the Ultraviolet Torch

Once you have marked your motorhome and any additional property with the ultraviolet security pen you can use the torch to view the markings, as ultraviolet ink is invisible to the naked eye.

Using the Microdot Applicator

The microdots should be applied over as wide an area as possible to give maximum coverage. Choose the area to apply the dots carefully, remembering they need to be accessible. Do NOT place on removable objects. It is fast, efficient, and easy to apply. Simply squeeze the applicator and brush on the micro dots where you want them to be applied. The dots will show as black specks on lighter surfaces.

Fitting the Master Window Label

The window label is to be placed on the inside of the nearside front habitation window of the motorhome, bottom left when viewed from outside. Using the microfibre cloth, ensure that the area is dry and clean of dirt or grease. Carefully remove the protective film of the label and firmly rub onto the window surface ensuring no air bubbles are present.

Fitting the Door Warning Label

Ensure the window area that you have chosen to place the door "WARNING" label is dry and clean of grease and dirt by wiping the area with the microfibre cloth. Carefully remove the protective film of the label and firmly rub onto the window surface ensuring no air bubbles are present. If your vehicle does not have a door window, apply to the nearest adjacent window.

Fitting the Tamper Evident Labels

The internal tamper evident labels can be placed in any position you choose. These are often best fitted to the inside of cupboard doors or the underside of drawers. Each label is made of tamper evident material designed to chip upon any attempt at removal. Ensure the area is dry and clean of the dirt and grease. Carefully remove the protective film of the label and firmly rub onto the surface ensuring no air bubbles are present.

Fitting the Tamper Evident Window Lozenges

The window lozenges are to be placed on the inside of all non-opaque windows. Placing the lozenges uniformly in the bottom right-hand corner of each window, where it will be visible and viewed from outside. Each tamper evident lozenge is made of tamper evident material designed to chip upon any attempt at removal. Using the microfibre cloth, ensure that the area is dry and clean of dirt or grease. Carefully remove the protective film of the label and firmly rub onto the window surface ensuring no air bubbles are present.

Fitting the Gas Locker Label

The gas locker label is to be placed inside the gas locker. The rear wall of the locker is recommended providing the label is visible when the gas bottles are in place. Each gas locker label is made of tamper evident material designed to chip upon any attempt at removal. Ensure the area is dry and clean. Carefully remove the protective film of the label and firmly rub onto the surface ensuring no air bubbles are present. Where there is no gas locker, this can be placed inside a wardrobe door.

Health & Safety for Lozenges & Labels:

Your safety in fitting this kit is of paramount importance, fitting your VIN CHIP kit is a non-hazardous process providing you follow the instructions carefully. These products are neither hazardous nor toxic, labels and lozenges may produce an allergic reaction if not handled correctly. However, the following describes possible accidents due to incorrect handling of the product and first aid treatment for such accidents.

Contact with eyes: This is not a hazardous substance. However, if the product has entered your eyes, wash eyes thoroughly with pure water for at least 15 minutes and consult a doctor.

Contact with skin: Wash your skin with cold or lukewarm water. If a rash develops or if there is any pain, consult a doctor.

Inhaling: This product is solid, thus there is no chance of inhalation.

Swallowing: This is not a hazardous substance. However, wash mouth roughly with pure water. If possible, put your finger into your throat to induce vomiting, and consult a doctor.

Health & Safety for Microdots:

Eye Contact: If this product comes in contact with the eyes, wash out immediately with fresh running water, ensure complete irrigation of the eye by keeping the eyelids apart and away from the eye moving the eyelids by occasionally lifting the upper and lower lids, seek medical attention without delay, if pain persists or reoccurs seek medical attention, removal of contact lenses after an eye injury should only be undertaken by skilled personnel.

Skin Contact: If skin contact occurs, immediately remove all contaminated clothing, including footwear. Flush skin and hair with running water (and soap if available). Seek medical attention in event of irritation.

Inhalation: If fumes, aerosols, or combustion products are inhaled remove from contaminated area. Other measures are usually unnecessary. Ingestion Immediately give a glass of water. First aid is not generally required. If in doubt, contact a Poisons Information Centre or a doctor.

Shelf life of microdots (providing the seal remains intact) is 6months

RFID Information: Store in dark conditions +20°C / RH 50%., Solvent free permanent adhesive is used. The RFID chip is fairly fragile.

Security Label Information: Handle with care. Ideal Store condition is 10~30°C and humidity is 70%RH or less. Do not allow moisture and chemicals in contact with the product.