

VIN CHIP PACK

SUITABLE FOR PRE 2016 MODELS



This pack includes all you need to retro fit your touring caravan to ensure it is protected by the VIN Chip police traceable scheme.

Your VIN Chip Pack contains:

- 1 x Master Window Label
- 1 x Gas Bottle Locker Warning Label
- 1 x Additional RFID Chip
- 10 x Tamper Evident Window Lozenges
- 1 x Lint free microfibre cloth

Simply follow the fitting instructions below. When you have completed the installation of the electronic chip, please call **CRiS on 0203 282 1000** to inform them of the location, so it can be securely recorded against your caravan VIN.

FITTING INSTRUCTIONS

Please read carefully before commencing installation

Fitting the electronic RFID chip

When choosing a location for your chip, bear in mind that it must be capable of being read by a police scanner at a 6m distance when travelling up to 60mph, without interference from any metallic surfaces.

The front and rear cupboards and wardrobes are ideal locations for application. Determine your location for the chip, ensuring that you have a large enough area. Ensure the surface is clean and dry, remove the backing paper and firmly rub the chip onto the surface.

The police need to be able to read the chip from outside the caravan. It can be read through almost any other non-metallic surfaces and materials such as - wood, glass, glass fibre reinforced plastic etc.

Fitting the internal tamper evident labels

Master Window Label

The Window Label is to be placed on the inside of the nearside, front window of the caravan, bottom left.



- Using the VIN Chip Microfibre cloth, ensure that the area is dry and clean of dirt or grease
- Partially peel the backing material away from the rear of the label and roll the label onto the surface
- Make sure that the label is firmly in place and contains no air bubbles by rubbing the rear of the label firmly

Gas Locker Label

The gas locker label is to be placed inside the caravan at the rear of the gas locker on the opposite side to the gas regulator. Each gas locker label is made of tamper evident material designed to chip upon any attempt at removal.

- Ensure the area you have chosen to apply the label to is sufficient for the size of the label
- Ensure that the area is dry and clean of dirt or grease
- Partially peel the backing paper away from the rear of the label and roll the label onto the desired surface
- Make sure that the label is firmly in place and contains no air bubbles by rubbing the front of the label firmly

Window Lozenges

The window lozenges are to be placed on the inside of all non-opaque caravan windows. Placing the lozenges uniformly in the bottom right hand corner of each window. Please exercise caution when removing the backing material of the lozenges as they contain 'security cuts' and it is possible to damage the labels if they are roughly handled at this stage.

- Ensure the area you have chosen to apply the label to is sufficient for the size of the label
- Using the VIN Chip Microfibre cloth, ensure that the area is dry and clean of dirt or grease
- Partially peel the backing material away from the rear of the label and roll the label onto the desired surface
- Make sure that the label is firmly in place and contains no air bubbles by rubbing the rear of the label firmly

NOW YOU HAVE COMPLETED INSTALLATION NOTIFY CRIS!

Call **CRiS 0203 282 1000** or email info@cris.co.uk to inform us where the electronic RFID chip has been fitted.

