

## VIN CHIP BUNDLE PACK SUITABLE FOR PRE-2016 MODELS

This pack includes all you need to retro fit your touring caravan to ensure it is protected by the VIN CHIP Police Forensic Scheme

### Your VIN CHIP Bundle pack contains:

- 2 x RFID Chips
- 6 x Tamper Evident Labels
- 10 x Tamper Evident Window Lozenges
- 1 x Gas Locker Label
- 1 x Master Window Label
- 1 x Door Warning Label
- 1 x Microdot Applicator
- 1 x UV Pen
- 1 x UV Torch
- 1 x Lint Free Microfibre Cloth



## FITTING INSTRUCTIONS

Please read carefully before commencing installation, exercise caution when removing the protective film or backing material of the labels and lozenges as they contain security cuts and it is possible to damage the item.

### Fitting the RFID Chip

When choosing a location for your chip, bear in mind that it must be capable of being read by a police scanner at 6m distance when travelling up to 60mph. The front and rear cupboards and wardrobes are potential locations for the application. Determine your location for the chip, ensuring that you have a large enough area. Ensure the surface is clean and dry, remove the backing paper and firmly rub the chip onto the surface. The police need to be able to read the chip from outside the caravan. It can be read through almost any other non-metallic surfaces such as wood, glass, glass-fibre reinforced plastic etc.

### Fitting the Master Window Label

The window label is to be placed on the inside of the nearside front window of the caravan, bottom left. Using the microfibre cloth, ensure that the area is dry and clean of dirt or grease. Carefully remove the protective film of the label and firmly rub onto the window surface ensuring no air bubbles are present.

### Fitting the Door Warning Label

Ensure the window area that you have chosen to place the door warning label is dry and clean of grease and dirt by wiping the area with the microfibre cloth. Carefully remove the protective film of the label and firmly rub onto the window surface ensuring no air bubbles are present.

### Fitting the Tamper Evident Window Lozenges

The window lozenges are to be placed on the inside of all non-opaque windows. Placing the lozenges uniformly in the bottom right-hand corner of each window. Each tamper evident lozenge is made of tamper evident material designed to chip upon any attempt at removal. Using the microfibre cloth, ensure that the area is dry and clean of dirt or grease. Carefully remove the protective film of the label and firmly rub onto the window surface ensuring no air bubbles are present.

### Fitting the Internal Tamper Evident Labels

The internal tamper evident labels can be placed in any position you choose. These are often best used on the inside of cupboard doors or the underside of drawers. Each tamper evident label is made of tamper evident material designed to chip upon any attempt at removal. Ensure the area is dry and clean of the dirt and grease. Carefully remove the protective film of the label and firmly rub onto the surface ensuring no air bubbles are present.

### Fitting the Gas Locker Label

The gas locker label is to be placed inside at the rear of the gas locker on the opposite side to the gas regulator. Each gas locker label is made of tamper evident material designed to chip upon any attempt at removal. Ensure the area is dry and clean of the dirt and grease. Carefully remove the protective film of the label and firmly rub onto the surface ensuring no air bubbles are present.

### Using the Ultraviolet Security Pen

A simple and easy way to further enhance the identity of your caravan is to write your home postcode on any removable items with the UV pen

### Using the Ultraviolet Torch

Once you have marked your caravan and any additional property using the ultraviolet security pen you can use the torch to view the markings, as ultraviolet ink is invisible to the naked eye.

### Using the Microdot Applicator

The microdots should be applied over as wide an area as possible to give maximum coverage. Choose the area to apply the dots carefully, remembering they need to be accessible. Do NOT place on removable objects. It is fast, efficient, and easy to apply. Simply squeeze the applicator and brush on the micro dots where you want them to be applied. The dots will show as black specks on lighter surfaces.

**Health & Safety for Lozenges & Labels:** Your safety in fitting this kit is of paramount importance, fitting your VIN CHIP™ kit is a non-hazardous process providing you follow the instructions carefully. These products are neither hazardous nor toxic, labels and lozenges may produce an allergic reaction if not handled correctly. However, the following describes possible accidents due to incorrect handling of the product and first aid treatment for such accidents. Contact with eyes - This is not a hazardous substance. However, if the product has entered your eyes, wash eyes thoroughly with pure water for at least 15 minutes and consult a doctor. Contact with skin - Wash your skin with cold or lukewarm water. If a rash develops or if there is any pain, consult a doctor. Inhalation - This product is solid, thus there is no chance of inhalation. Swallowing - This is not a hazardous substance. However, wash mouth roughly with pure water. If possible, put your finger into your throat to induce vomiting, and consult a doctor.

**Health & Safety for Microdots: Eye Contact:** If this product comes in contact with the eyes, wash out immediately with fresh running water, ensure complete irrigation of the eye by keeping the eyelids apart and away from the eye moving the eyelids by occasionally lifting the upper and lower lids, seek medical attention without delay, if pain persists or reoccurs seek medical attention, removal of contact lenses after an eye injury should only be undertaken by skilled

Personnel. **Skin Contact** If skin contact occurs: Immediately remove all contaminated clothing, including footwear. Flush skin and hair with running water (and soap if available). Seek medical attention in event of irritation. **Inhalation** If fumes, aerosols, or combustion products are inhaled remove from contaminated area. Other measures are usually unnecessary. **Ingestion** Immediately give a glass of water. First aid is not generally required. If in doubt, contact a Poisons Information Centre or a doctor. Shelf life of microdots (providing the seal remains intact) is 6months

**RFID Information:** Store in dark conditions +20°C / RH 50%, Solvent free permanent adhesive is used. The RFID chip is fairly fragile.

**Security Label Information:** Handle with care. Ideal Store condition is 10~30°C and humidity is 70%RH or less. Do not allow moisture and chemicals in contact with the product.